

HEAVY-DUTY DOOR HINGES



INSTALLATION INSTRUCTIONS

JP54-036
2-Door Hinges

JP54-037
4-Door Hinges

Tools Needed

Stock Hinge Removal: 13mm socket and T-50 Torx bit

H-D Hinge Installation: 13mm socket (deep well socket or extension) and a 5mm Allen wrench



STEP 1

Remove the pin nut from the bottom side of the door hinge using a T-50 Torx socket.



STEP 2

Leaving the door latched, remove the factory Torx bolts from the door hinge using a T-50 Torx socket.



STEP 3

Remove the factory hinge from the Jeep.



STEP 4

Insert the new MORryde hinge.



STEP 5

Line up the holes in the hinge with the holes and the threaded plate in the door.



STEP 6

Install the hinge using both of the supplied M8 x 1.25 SS button head bolts.

STEP 7

Repeat Steps 2-6 for the remaining hinges.

MORryde

HEAVY. DUTY. ADVENTURE.

www.MORryde.com • 574.293.1581