

JP54-070

OVERHEAD STORAGE LOCK BOX



INSTALLATION INSTRUCTIONS

NOTE: Installing the Overhead Lockbox is easiest with an assistant to help hold the Lockbox in place when bolting it to the roll bar. -

TOOLS NEEDED

- 13mm Wrench
- 1/2" Wrench
- 9/16" Wrench



STEP 1

Unzip the top cover of the rear roll bar cover to locate the threaded holes in the roll bar.



STEP 2

Cut slits in roll bar lining to allow supplied 8mm bolt to pass through the mounting brackets and into the holes you located in Step 1.



STEP 3

Install supplied 8mm bolts, securing the Lockbox to the roll bar.



STEP 4

Position support bar with the mounting brackets behind the roll bar. Insert the supplied U-bolts and through the mounting brackets, and loosely install the supplied spacers and nuts on the U-bolts.



STEP 5

Adjust the location of the brackets on the roll bar so the Lockbox sits level and tighten the nuts on the U-bolts.



STEP 6

Secure the Lockbox for travel by inserting the support bar into the clips on the bottom of the Lockbox.

MORryde

HEAVY. DUTY. ADVENTURE.

MORryde.com • 574.293.1581