

STEP TREAD COVERS

INSTALLATION INSTRUCTIONS

INSTALLATION

Adhesive marine-grade RV step tread covers help to prevent dirt tracking into the unit.

Tools Required:

- Cloth Towels
- Rubbing Alcohol
- Thin-bladed Tool

STEP 1

Test-fit the Step Tread Cover onto step(s) to ensure that they are the proper size.



STEP 2

Ensure step tread is bare; being free of any covering(s) and/or traction/tread tape.

Note: A thin-bladed tool such as a razor blade can be used to assist in the removal of tread tape.



STEP 3

To remove tread tape, at a slight angle, put the edge of the blade under the corner of the tape. Begin to slowly peel the tape by wiggling it back and forth. It is much easier to remove when tape is warmed.



Above. Beyond. Always.

STEP TREAD COVERS

STEP 4

Use rubbing alcohol to clean the entire step tread surface.



STEP 5

Once the surface has been cleaned, allow time for any remaining alcohol to evaporate. Once evaporated, use a clean dry cloth to wipe the step tread again ensuring any film left behind has been removed.

STEP 6

Place Step Tread Cover onto step and slowly peel the adhesive backer off as the tread cover is firmly pressed into place on the step tread.



STEP 7

Once complete, proceed to the next tread and follow/repeat the above steps to install covers on each of the remaining steps.

Questions? Contact the Parts Department at 574-293-1581 or email parts@morryde.com.



SCAN ME for the
Installation Video



Step Tread Covers | VERSION 1

574.293.1581 • MORryde.com

