



# SAFE T RAIL

## FOR MOTORHOMES

INSTALLATION INSTRUCTIONS



SP56-632



Above. Beyond. Always.

# SAFE-T-RAIL FOR MOTORHOMES

## INSTALLATION INSTRUCTIONS

### INTRODUCTION

The **Motorhome Safe-T-Rail** is a telescoping support/handrail that replaces the small door handle, and when fully engaged, extends 16 inches from the motorhome wall it attaches to. When extended, the Safe-T-Rail is designed to provide nearly 3' of continuous surface rail support for walking up and down motorhome steps. When not in use, the Safe-T-Rail is designed to collapse and remain securely closed via a 120lb magnet.

#### Tools Required:

- Drill/Impact
- 1/8" Drill Bit
- Screw Bit Driver
- 2-7/16" Wrenches
- Silicone Caulk
- (4) #12 1" Mounting Screws

### PREPARATION

#### General Safety & Warnings:

**⚠ WARNING** Read and understand all instructions and warnings prior to installation.

**⚠ WARNING** Failure to follow the instructions and heed the warnings of this document may result in injury, damage to the trailer and/or property, and/or voidance of the product warranty. Always utilize appropriate safety equipment, i.e. proper eye protection, hearing protection, gloves, etc.

**⚠ WARNING** You are personally responsible for following safe installation procedures and completing appropriate safety checks.

**⚠ WARNING** Due to the variety of installation applications, mounting clearances, and surface materials, a generic hardware pack is supplied for convenience. It is at the discretion of the installer to choose the hardware that best suits specific needs. MORryde does not take ownership of any wrongly installed rails or damage that may result from a wrongfully installed rail.

**NOTE:** The installation pin may or may not line up with the holes, depending on the OEM installation. The pin is not required for proper function or storing of the Safe-T-Rail and is strictly an option. If the pin does not line up, it is not necessary to have the hole drilled out to accommodate the pin.



Above. Beyond. Always.

# SAFE-T-RAIL FOR MOTORHOMES

## INSTALLATION INSTRUCTIONS

### INSTALLATION

#### ASSEMBLY INSTRUCTIONS

While the Safe-T-Rail ships with the Support Arm (1), Main Handrail Arm (2), and Inner Handrail Arm (3) already attached to the Lower Bracket (7) the end user/ installer will need to attach the Main Handrail Arm (1) Upper/Top Mount Bracket (6 or 8) utilizing a 1/4-20 x 2.5" Bolt (10), two Nylon Washers (13) and 1/4-20 Locking Nut (12).

**NOTE:** Prior to installing any screws, butt the top of the lower Safe-T-Rail bracket up against the bottom of the door frame and move the edge of the Safe-T-Rail against the side of the door and ensure that the entire lower bracket rests against the RV wall evenly, allowing for both the door and the slide (if applicable) to open and close without obstruction.

#### STEP 1

Ensure the Safe-T-Rail install location is clean and free of debris.

#### STEP 2

Open the Safe-T-Rail and place it in the desired mounting location, then use the drill and 1/8" bit to mark each of the four mounting hole locations.

#### STEP 3

Set the Safe-T-Rail down, and using the 1/8" bit, drill pilot holes in the marked location from the previous step.

#### STEP 4

Fill each of the pilot holes (and any holes from the prior rail/support device) with a liberal amount of silicone caulk.

#### STEP 5

Line up the mounting holes on the open Safe-T-Rail with the caulked pilot holes. Once lined up, use the screw bit driver to install one of the mounting screws into the upper-most mounting hole.

#### STEP 6

Ensure all other mounting holes are lined up, then install the remaining three screws.

#### STEP 7

Open and close the Safe-T-Rail to ensure it opens and closes smoothly.



# SAFE-T-RAIL FOR MOTORHOMES

## INSTALLATION INSTRUCTIONS

### TROUBLESHOOTING

Please contact MORryde Customer Service should mechanical difficulties occur that interfere or impede the functionality/normal operation of the Safe-T-Rail.

**1966 Sterling Avenue Elkhart, IN 46516 | 574.293.1581 | Sales@MORryde.com**

Safe-T-Rail  
for Motorhomes  
VERSION 3



Above. Beyond. Always.

574.293.1581 • MORryde.com

