



FOLDING STEP KICKPLATE REPLACEMENT


NUTS & BOLTS INSTALLATION PROCEDURE

INSTALLATION



STEP 1

Drill out (4) rivets holding original kickplate in place using a 3/16" drill bit. There will be (2) on the left side and (2) on the right side.



STEP 2

Begin drilling (4) starter holes on the inside of the tube using a 5/16" drill bit. Make sure these new holes line up with the holes on the outside where the rivets were previously installed.



Above. Beyond. Always.

574.293.1581
www.MORryde.com

FOLDING STEP KICKPLATE REPLACEMENT

NUTS & BOLTS INSTALLATION PROCEDURE

INSTALLATION


STEP 3

Continue to drill the holes using a 3/8" drill bit.
Finish drilling the holes using a 5/8" drill bit



STEP 4

You will now need a 1/4" drive, a 3" long extension with a 3/8" socket attached. Install the provided (4) bolts on the outside of the tube and the (4) provided nuts on the inside of the tube using the ratchet to hold the nuts in place. The holes on the inside are clearance holes used to insert the nuts to tighten down the kickplate. The holes will be left open after installation.



Questions? Contact the Parts Department at **574-293-1581** or email parts@morryde.com.



Above. Beyond. Always.

574.293.1581
www.MORryde.com