



SCISSOR JACK STABILIZER

INSTALLATION INSTRUCTIONS



SP54-181



Above. Beyond. Always.



Above. Beyond. Always.



SCISSOR JACK STABILIZER

INSTALLATION INSTRUCTIONS

INTRODUCTION

A collaboration with Winfield RV Products, the X-Brace Scissor Jack Stabilizer system is designed to provide enhanced lateral support to stabilize units when parked.

PARTS LISTING

Item	Qty	Description
1	1	Extender Tool
2	2	3/8" x 4-1/2" Bolts
3	2	3/8" x 5" Bolts
4	4	3/8" Lock Nuts
5	4	3/8" Spacers
6	4	1/4" Washers
7	4	1/4" x 1-1/2" Sleeves
8	2	1/4" x 4-1/2" Bolts
9	2	1/4" x 5" Bolts
10	4	1/4" Nylock Nut

Tools Required:

- (2) 9/16" Wrenches
- (2) 7/16" Wrenches
- Tape Measure

PREPARATION

General Safety & Warnings:

- ⚠ WARNING** Read and understand all instructions and warnings prior to installation.
- ⚠ WARNING** You are personally responsible for following safe installation procedures and completing appropriate safety checks.
- ⚠ WARNING** Be sure the unit is leveled properly before proceeding.

SCISSOR JACK STABILIZER


INSTALLATION INSTRUCTIONS

INSTALLATION

STEP 1 Lower the scissor jacks until they barely touch the ground. Do not apply any tension.



STEP 2 Where the scissor jacks are attached to the frame or RV, measure the distance from the center of one scissor jack to the center of the other scissor jack. If the measurement is between 61" and 72", continue to **STEP 4**. If the measurement is greater than 72", the cross brace must be extended as described in **STEP 3**. If measurement is less than 61", the product will not fit your unit.



STEP 3 On 5th wheels or travel trailers where the distance between the scissor jacks is wider than 72", the cross braces must be extended to compensate for a wider install. If this applies, remove the bolt and nut at the end of the smaller tube. Extend the tube by pulling the end of the rod out by 5". Reinsert and tighten the bolt and nut.





Above. Beyond. Always.

SCISSOR JACK STABILIZER


INSTALLATION INSTRUCTIONS

INSTALLATION

STEP 4 Assemble the cross brace sections. Insert the inner square tube into the outer square tube. On the larger outer square tube, the mounting hole should be positioned upward. On the smaller tube, the mounting hole should be positioned downward. Twist the tensioning rod to ensure the inner tube is seated completely into the outer tube. If it is properly seated, the inner tube will expand when the tensioning rod is turned clockwise. Once seated, rotate the tensioning rod counterclockwise until it stops, and the cross brace is at its shortest length.



STEP 5 LOWER ASSEMBLY — On one side of the RV, remove the inner bolt at the bottom of the jacks that holds the lower assembly and the jack foot. Identify if this bolt is 3/8" or 1/4". If the bolt is 3/8", replace the scissor jack bolt with the provided 3/8" x 4-1/2" bolt. If the bolt is 1/4", use the 1/4" x 4-1/2" bolt and sleeve in place of the 3/8" bolt. Insert the bolt into the scissor jack from the right side of the jack. Place the spacer on the bolt and slide the small end of the cross brace onto the bolt. The cross brace should be installed on the left side of the jack. Tighten the nut and bolt until all the slack is out of the bolt. Do not overtighten.



Spacer

SCISSOR JACK STABILIZER

INSTALLATION INSTRUCTIONS


INSTALLATION

STEP 6 UPPER ASSEMBLY — On the same side of the RV, using the second X-Brace (at the adjustment end) remove the inner bolt at the top of the jacks that goes into the upper assembly. Identify if this bolt is 3/8" or 1/4". If the bolt is 3/8", replace the scissor jack bolt with the provided 3/8" x 5" bolt. If the bolt is 1/4", use the 1/4" x 5" bolt and sleeve in place of the 3/8" bolt. Insert the bolt into the scissor jack from the right side of the jack. Place the spacer on the bolt and slide the small end of the cross brace onto the bolt. The X-Brace should be installed on the left side of the jack. Tighten the nut and bolt until all the slack is out of the bolt. Do not overtighten.



STEP 7 Repeat STEPS 5 and 6 on the other side of the RV.

STEP 8 Retract both scissor jacks to ensure they come up completely. With both jacks fully retracted, rotate the tensioning rod clockwise on both X-Braces until there is a slight amount of resistance.



Scan Code
for Install Video



Above. Beyond. Always.

SCISSOR JACK STABILIZER

OPERATING INSTRUCTIONS

TO ENGAGE

- STEP 1** Lower your scissor jacks to the ground and tension them as usual. Make sure the scissor jacks are bearing the weight of the RV.
- STEP 2** Connect the extender tool to the tensioning rod and extend it by turning the handle clockwise. Once you feel tension, rotate the handle another half turn and stop.

NOTE: Do not over tension or the X-Brace will begin to spread the bottom of the scissor jacks apart.

TO DISENGAGE

- STEP 1** Relieve the tension from the X-Brace by rotating the tensioning rod counter-clockwise. Approximately 20-25 turns is usually sufficient, but more turns may be required if the scissor jacks are extended further than normal.
- STEP 2** Once the tension has been backed off, you can retract your scissor jacks as usual.

Questions? Contact the Parts Department at **574-293-1581** or email parts@morryde.com.

At MORryde, we have a passion for solving problems. Whether we're fabricating custom solutions, modifying a commercial chassis, or creating our innovative products, we answer to a wide range of markets and deliver on a variety of needs. At MORryde, it's simply about doing MORE for our customers, and it doesn't stop at the sale. We stand behind our products, believing in quality first, service always. No matter the issue, we'll be the first to respond and the last to be satisfied. In short, we build better — together.

SP54-181 | VERSION 5



Above. Beyond. Always.

574.293.1581 • www.MORryde.com •    